



VANE AIR COMPRESSOR CONTROLLER

MODLE: MAM-860

USER

MANUAL

NAILI GROUP

2018.05.01

Notice



Please read all the operation manual before operating the set and keep this manual for further reference.



Installation of MAM—8** compressor controller can be performed only by professional technicians.



Installation position shall be considered carefully in order to ensure good ventilation and reduce electromagnetic interference.



Wiring shall be performed respectively according to regulations for heavy and weak current to reduce electromagnetic interference.



RC snubber must be connected to the two terminals of coil (such as AC contactor ,valve, etc),which are controlled by relay output.



Port connection shall be inspected carefully before power on.



Correct ground connection (the third ground)can help increase product capacity of resisting signal interference.



Set rated current of motor: the max current of motor/1.2.

Features:

- Chinese / English or Spanish/English display.
- Remote control/Local control.
- Block mode/Independent mode.
- On-off control of motor.
- Prevention for air compressor reversion.
- Temperature measurement, control and protection.
- Voltage measurement and protection.
- RS485 communication function, supporting MODBUS RTU protocol.
- Protection for open phase, overload current, unbalance current, high voltage, low voltage.
- High integration, high reliability, high cost performance.

Contents

1, Basic Operation	- 3 -
1, Button Explanation	- 3 -
2, Indicator Instruction.....	- 4 -
3, Status Display and Operation	- 4 -
4, Operating Parameter and Menu	- 4 -
5, User Parameter View and Modification:.....	- 5 -
6,User Parameter Sheet and Function.....	- 6 -
7, Factory Parameter View and Modification	- 8 -
8, Factory Parameter Sheet and Function	- 9 -
9, Calibration Parameter	- 10 -
10, Operating Authorization and Password	- 11 -
2, Controller Function and Technical Parameter	- 11 -
3, Model and Specification	- 12 -
1, Model Description	- 12 -
2, Power consumption Table for Corresponding Motor.....	- 13 -
4, Installation	- 13 -
1, Mechanical Installation.....	- 13 -
2,Electrical Wiring Installation.....	- 15 -
5, Control Process.....	- 16 -
1, Single Machine	- 16 -
2, Net Work.....	- 17 -
3, Fan Operation	- 17 -
6, Alarm Function	- 18 -
1, Air Filter Alarm.....	- 18 -
2, Oil Filter Alarm.....	- 18 -
3, O/A separator Alarm.....	- 18 -
4、Lubricating Oil Alarm.....	- 18 -
5, Grease Alarm	- 18 -
6, Belt Alarm.....	- 18 -
7, High Discharge Air Temperature Alarm	- 18 -
7, Controller Protection	- 18 -
1, Motor Protection.....	- 18 -
2, Protection of High Discharge Air Temperature	- 19 -
3, Protection of Air Compressor Non-reversing	- 19 -
4, Protection of High Pressure	- 19 -
5, Protection of Sensor Failure	- 19 -
8, Troubleshooting.....	- 19 -
1, This Fault Review.....	- 19 -
2, Common Failures and Causes.....	- 20 -
9, Block mode control and net work.....	- 20 -
1, Block mode control.....	- 20 -
2. Net Work.....	- 22 -
10. Schematic Diagram.....	错误!未定义书签。

1, Basic Operation

1, Button Explanation




Figure 1.1.1



——Start Button:

- 1, When compressor is at stop status, press this button to start the compressor.
- 2, When compressor is set as master (No.1) in block mode, press this button to start the compressor and activate block mode function at the same time.



——Stop Button:

- 1, When the compressor is at running status, press this button to stop the compressor;
- 2, When compressor is set as master (No.1) in block mode, press this button to stop compressor and block mode function as well;
- 3, When compressor is at stop status, long press this button to display software edition.



——Set Button /Loading / unloading Button:

- 1, When the compressor is at running status, press this button to load, unload;
- 2, When the compressor is at setting mode, press this button after modification to confirm and save the modified data.
3. When password input to check the password is correct or incorrect;



——Move down button / Decreasing button:

- 1, When viewing the menu, press this button to move downward the cursor;
- 2,When modifying data, press this button to decrease the data at current position.



——Move up button/Increasing button:

- 1, When viewing the menu, press this button to move upward the cursor;
- 2, When modifying data, press this button to increase the data at current position.



——Shift button /Enter button:

- 1, When modifying data, press this button to move to the next data bit;
- 2, When select menu, press this button to switch to submenu. If no submenu available, the controller will shift to data setting mode.



——Return button / Reset button:

- 1, When modifying data, press this button to exist data setting mode;
- 2, When viewing the menu, press this button to return to previous menu;
- 3, When the controller is at failure stop status, long press this button to reset.

2, Indicator Instruction



Power Indicator: Indicator on when controller is energized.

Operation indicator: Indicator is on when motor is running.

Error indicator: Indicator is blinking when alarming; indicator on when fail to stop; indicator off when error is cleared



3, Status Display and Operation

The display screen will show as below after power on:





After power on, show this menu

After 5 seconds, the menu will switch as below:



Main menu


Press “” to enter into Selection Menu:



Level 1 menu

4, Operating Parameter and Menu

Press “” to move the cursor to “RUN PARAMETER”, then press “” to switch to the secondary menu:



HISTORY FAULT
PRODUCTION DATE、 NUM.
THIS FAULT
COM STATUS

Move the cursor to the corresponding menu item, press “▶” to check the specific parameter. Such as viewing "MOTER FAN CUR ", move the cursor to the “MOTER FAN CUR " menu item, press the “▶”, switch to the item of motor , fan data .

MAIN (A)	FAN (A)
A 50.1	2.1
B 50.1	2.1
C 50.1	2.1

Press the “◀” to return to the previous menu or the main menu. If no operation at the current menu for 60 Seconds.

5, User Parameter View and Modification:

In first menu, press the “▲” and “▼” to move the cursor to the "USER PARA." item, press the “▶” to switch to the following menu:

P、 T SET
SET TIME
OPERATION MODE
BLOCKING MODE

CLR LIFE TIME
MAX LIFE TIME
LANG. LANG. SELECT CH/EN
NEW USER PIN: ****

Move the cursor to the "P、 T SET " item, then press “▶” to switch to the following menu:

LOAD P: 00.62 MPa
UNLOAD P: 00.78MPa
FAN START T: 0080°C
FAN STOP T: 0075°C

Move the cursor to the “LOAD P” item, then press “▶” to switch to the following menu which requires a user password input.

INPUT CODE

In this menu, the first data bit of password started blinking, press “▲” or “▼” to modify the first bit of password, Press the “▶”, move the cursor to the next data bit, modify the second data of password. In accordance with the above, modify the third and fourth data of password in sequence. Press“ S” to confirm the input data and the menu will switch to the following menu after verification:

LOAD P: 00.62 MPa *
UNLOAD P: 00.78MPa
FAN START T: 0080°C
FAN STOP T: 0075°C

The upper right corner with "*" Indicates the system verification of the password

In the menu above, press “▶”, the first data of loading pressure starts to blink, user can press “▲” or “▼” to modify the present data in accordance with the above method .Press “▶” to move to next data bit and modify to the target data in sequence. When finished, press “ S” to confirm and save the data. The controller prompt sends out a short voice to tip the completion of parameter set.




6,User Parameter Sheet and Function

First menu	Second menu	Preset Data	Function
SET P. T.	LOAD P.	0*.*MPa	1, In AUTO LOADING, compressor will load if pressure is below this set data 2, In STANDBY mode, compressor will start if the pressure is below this set data
	UNLOAD P.	0*.*Mpa	1, Compressor will unload automatically if air pressure is above this set data 2, This data should be set above LOAD P ,also should be set below ULD LIM P
	FAN START T	0120°C	Fan will start if discharge air temperature is above this set data
	FAN STOP T	0000°C	Fan will stop if discharge air temperature is below this set data
TIME SET	MOTOR DELAY	0008S	Set the master start time, record time when master is activated, controller will not start overload protection during this time to avoid stopping the master by impulse starting current
	FAN DELAY	0006S	Set the fan start time, record time when fan is activated, controller will not start overload protection during this time to avoid impulse starting current stopping the fan.
	STAR DELAY	0000S	Time from star start to delta start.
	LOAD DELAY	0002S	Unloading in this set time after enter delta running
	UNLOAD DELAY	0240S	When unloading continuously, compressor will automatically stop and enter to standby status if over this set time
	STOP DELAY	0010S	For NORMAL STOP operation, compressor will stop after it continuously unloading over this set time

	START DELAY	0100S	Machine can be restarted only over this set time at any case(after NORMAL STOP, STANDBY or FAILURE STOP)
OPERATION MODE PRESET	ON/OFF MODE	LOCAL/REMOTE	Set local, remote cannot control it; Set remote, local cannot control it.
	LOAD MODE	AUTO/MANU	1,When set as the MANU: only when the pressure is above “unloading pressure”, compressor will unload automatically .For any other case, the Loading/Unloading function can only be executed by pressing “loading /unloading ” key. 2,When set as AUTO ,the loading/ unloading function can be executed by the fluctuation of air pressure automatically
	COM MODE	BAN /SEQ./MODBUS	1,When set as BAN, the communication function is invalid. 2,When set as SEQ. ,compressor function as a slave and is able to communicate with computer or DCS 3,When set as MODBUS, compressor can net control
	COM ADDRESS	0001	Set the communication ADD in block mode or when communicate with monitoring center. This ADD is unique for every controller in net;
BLOCKING MODE SETTING	BLOCK MODE	MASTER/SLAVE	1,When service as master in BLOCK. Master controls slave, the COM ADDRESS should be No.1 2,When service as slave in BLOCK, slave is controlled by master
	TURN TIME	0099 Hours	When master pressure is between BLOCK LOAD P and BLOCK UNLOAD P, master determine slave work alternatively over this set time .
	BLK NUMER	0000	Number of air compressors in block net
	BLK MIN	**.**MPa	In BLOCK, one compressor will start or load when pressure is below this set data
	BLK MAX	**.**MPa	In BLOCK mode, one compressor will stop or unload when pressure is above this set data
	BLK DELAY	0050S	In BLOCK mode, when master sends two commands continuously, second command signal delays for this set data.
CLR LIFE TIME	OIL FILTER	0000H	Record total running time of oil filter, if changing new oil filter, the data should be reset by manual operation.
	O/A SEPARATOR	0000H	Record total running time of O/A separator. If changing new O/A separator, the data should be reset by manual operation
	AIR FILTER	0000H	Record total running time of air filter .If changing new air filter, the data should be reset by manual operation
	LUBE	0000H	Record total running time of lube. If changing lubricate ,the data should be reset by manual operation
	GREASE	0000H	Record total running time of grease. If changing new grease, the data should be reset by manual operation
	BELT	0000H	Record total running time of belt. If changing new belt, the data should be reset by manual operation

MAX LIFE TIME PRESET	OIL FILTER	9999H	1,Alarm prompts when total running time of oil filter is above the set data. 2,Set this data to “0” to clear oil filter running time
	O/A SEPARATOR	9999H	1,Alarm prompts when total running time of O/A separator is above the set data. 2,Set this data to “0” to clear O/A separator running time
	AIR FILTER	9999H	1,Alarm prompts when total running time of air filter is above the set data. 2,Set this data to “0” to clear air filter running time
	LUB	9999H	1,Alarm prompts when total running time of lubricate is above the set data. 2, Set this data to “0” to clear lubricate running time.
	GREASE	9999H	1,Alarm prompts when total running time of grease is above the set data. 2,Set this data to “0” to clear grease running time
	BELT	9999H	1,Alarm prompts when total running time of belt is above the set data. 2,Set this data to “0” to clear belt running time .
LANG.SEL	EN/CH	EN	1,Set to “EN” , Display in English 2,Set to “CH” , Display in Chinese
NEW USER PIN	****	****	User could modify the user password by old user password or factory password

7, Factory Parameter View and Modification

FACTORY PARAMETER store relatively parameter set by factory. To check FACTORY PARAMETER, you have to verify password first. In the first menu, press “” and “” to FACTORY PARAMETER, press “”to switch to the menu below.

INPUT CODE

Input the correct password to switch to the FACTORY PARAMETER menu as below:

MOTOR CUR: 100.0A
FAN CUR: 010.0A
ALARM T: 0105°C
STOP T: 0110°C

STOP P: 00.90MPa
 MAX U.L.: 00.85MPa
 RUN TIME: 001234H
 LOAD TIME: 001001H

For more factory parameter, please check factory parameter sheet. When modify factory parameter, please refer to customer parameter modification method, supper password is required to set TOTAL RUN TIME, PHASE PROT, POWER FREQ and MAX RUN TIME.

8, Factory Parameter Sheet and Function

PARAMETER	Initial Data	Function
MOTOR CUR	Maximum motor overload data /1.2	When the current of motor is more than 1.2 times of the set data, the unit will stop for overload feature. (see table2.1.1)
FAN CUR	Maximum fan overload data/1.2	When the current of fan is more than 1.2 times of the set data, the unit will stop for overload feature.
ALARM T.	105℃	When discharge air temperature reaches this set data, compressor will alarm
STOP T.	110℃	When the discharge air temperature reaches this set data, compressor will alarm and stop
STOP P.	1.00MPa	When pressure reaches this set data ,compressor will alarm and stop
MAX U.L.	0.80MPa	This data is the maximum of UNLOADING P. The UNLOADING P in the customer parameter must be set no higher than this data.
RUN TIME	000100Hours	Modify the TOTAL RUN TIME
LOAD TIME	000095Hours	Modify the TOTAL LOAD TIME
CLR FAULT	****	Input the password 8888 and press “set “button to clear all the history failure record.
CUR UN.BAL.	0006	MAX-MIN \geq SET*MIN/10 ,respond time is 5s If the set data \geq 15, the unbalance protection will be invalid.
OPEN PAHSE	002.0s	If OPEN PHASE protection \geq 20 seconds, OPEN PHASE protection is invalid
PROD DATE	****_**_**	Production date
PROD NO	*****	Product serial No.
PHASE PROT..	ON/OFF	ON: turn on phase sequence protection OFF: turn off phase sequence protection
POWER FREQ	50HZ/60HZ	Set the operation power frequency
BLK MODE	ADV/COMPATIBLE	Set as compatible mode, block mode is the same as the other series controller by PLOT When block control with MAM 8*0 controller and set as advanced mode, more block mode function is available
HIGH VOL.	0460V	1, Controller detects the voltage higher than this set data, the shutdown protection starts and reports HIGH VOL. 2,Set this data to 0000, the HIGH VOL. protection function is invalid
LOW VOL.	0320V	1, Controller detects the voltage lower than this set data, shutdown protection starts and reports LOW VOL. 2,Set this data to 0000, the LOW VOL. protection function is invalid
LOW T PRO-	-0048℃	1,In stop mode, air compressor is not allowed to start when discharge air temperature is lower than this set data 2,Two minutes after turn on, when the air temperature is below this data, compressor will stop and display T SENSOR FAULT
TIME LIM	0000H	1,When the compressor is in a stop status and the TOTAL RUN TIME exceeds this TIME LIM set, the controller will stop the

		compressor and display USER MISTAKE; 2,If this data is set to '0000', TIME LIMIT function is invalid.
ALM STOP	0010H	Controller detects oil filter, O/A separator, air filter, lubricate oil ,grease and belt running with alarming over this ALARM STOP set, compressor will stop and report "ALARM LONG STOP "
COM PARA	SET ON/OFF	1,When set as ON, User can use DCS to set data through MODBUS protocol; 2,When set as OFF, User cannot use DCS to set data through MODBUS protocol 3, User can use DCS to set data only when compressor is at stop status
PARA1	****	User could modify the factory password by old factory password.

9, Calibration Parameter

You can set relative data of controller in CALBR PARA. It is not allowed to view and modify without manufacturers authorization, so please verify the password before view and modification. The modification of CALBR PARA is similar with CUSTOMER PARA. Main function is shown as below.

PARAMETER		Initial Data	Function
MOTOR A	TARGET CUR	0000	1,When calibrate the current of motor A, revise standard current data, controller calibrate the current by figuring the current coefficient and save the data automatically 2,Standard current data will return to zero after calibration
	COEF	1.000	When calibrate the current, revise coefficient. Current data in display=sample data*coefficient
	CUR	***.*A	This data is qret
MOTOR B	TARGET CUR	0000	1,When calibrate the current of motor B, revise standard current data, controller calibrate the current by figuring the current coefficient and save the data automatically 2,Standard current data will return to zero after calibration
	COEF	1.000	When calibrate the current, revise coefficient. Current data in display=sample data*coefficient
	CUR	***.*A	this data is qret
MOTOR C	TARGET CUR	0000	1,When calibrate the current of motor C, revise standard current data, controller calibrate the current by figuring the current coefficient and save the data automatically 2,Standard current data will return to zero after calibration
	COEF	1.000	When calibrate the current, revise coefficient. Current data in display=sample data*coefficient
	CUR	***.*A	this data is qret
FAN A	TARGET CUR	0000	1,When calibrate the current of fan A, revise standard current data, controller calibrate the current by figuring the current coefficient and save the data automatically 2,Standard current data will return to zero after calibration
	COEF	1.000	When calibrate the current, revise coefficient. Current data in display=sample data*coefficient

	CUR	***.*A	this data is qret
FAN B	TARGET CUR	0000	1,When calibrate the current of fan B ,revise standard current data, controller calibrate the current by figuring the current coefficient and save the data automatically 2,Standard current data will return to zero after calibration
	COEF	1.000	When calibrate the current, revise coefficient. Current data in display=sample data*coefficient
	CUR	***.*A	this data is qret
FAN C	TARGET CUR	0000	1,When calibrate the current of fan C ,revise standard current data, controller calibrate the current by figuring the current coefficient and save the data automatically 2,Standard current data will return to zero after calibration
	COEF	1.000	When calibrate the current, revise coefficient. Current data in display=sample data*coefficient
	CUR	***.*A	this data is qret

10, Operating Authorization and Password

Controller provides multiple passwords and access management. According to different levels of passwords, controller provides different levels of operating authorization, details as following:

1. User operation password: fixed:_____

Permissions: allows to modify the LOADING P, UNLOADING P, FAN START T, FAN START T, ON/OFF MODE, LOAD MODE, COM MODE, COM ADD and BLOCKING MODE.
2. New user password: factory set:_____

Permissions: Allows to modify all CUSTOMER PRAMETER.
3. Mmanufacturer sales password: factory set:_____

Permissions: Allows users to modify all CUSTOMER PRAMETER, the NEW USER PIN, some MANUFACTURER PARAMETER, MANUFACTORY SALES PASSWORD.
4. Mmanufacturer operation Password: fixed:_____

Permissions: Allows users to modify all CUSTOMER PRAMETER, the NEW USER PIN, some MANUFACTURER PARAMETER, MANUFACTORY SALES PASSWORD.
5. Calibrate Password: fixed:_____

Permissions: Allows users to calibrate currents in CALBR PARAMETER.
6. Super Password: fixed:_____

Permissions: Allows users to modify TOTAL RUN TIME,PHASE SEQUENCE PROTECTION, OPWER FREQUENCY ,TIME LIMIT after user enter factory parameter and verify supper password.

2, Controller Function and Technical Parameter

- 1, Digital input&output: 3 points of digital input ;5 points of digital relay output ;
- 2, Analog input: 1 point of Pt100 temperature input ; 1 point of 4~20mA pressure signal input; two groups of

three phases current inputs(CT provided);

3, Input voltage of phases:380V/220V;

4, Compressor protection of high operation voltage and low operation voltage

5, Controller power supply: AC16-28V、 50/60HZ、 0.3A、 5VA (recommend 10VA)

6, Measurement:

①、 Discharge air temperature:-50~150℃; Accuracy:±1℃.

②、 Operation time: 0~999999 hours.

③、 Current:0~999.9A.

④、 Pressure: 0~1.60MPa. Accuracy: ±0.01Mpa.

7,Phase sequence protection: When compressor is at stop mode and detects wrong phase sequence, respond time≤1s (optional);

8, Open phase protection: When compressor is at stop mode and detects open phase ,respond time≤1s

9, Motor protection: This controller has the following basic protection function for main motor and overload protection for fan.

①、 Open phase protection: When any phase opens, the respond time equals to set time, when phase open time is set above 20s,open phase protection is invalid;

②、 Unbalance protection: when $MAX-MIN \geq SET*MIN/10$,respond time is 5s;

③、 Protection features of overload (time unit: second), please see following table (table 2.1.1), multiple

$=I_{actual} / I_{set}$,motor operates with delay time according to overload multiples and operation time shown in following table (table 2.1.1) when motor working current is higher or equal to the set current from 1.2 times and 3.0 times .

I_{actual}/I_{set}	≥ 1.2	≥ 1.3	≥ 1.5	≥ 1.6	≥ 2.0	≥ 3.0
Time parameter						
Response time (S)	60	48	24	8	5	1

Table 2.1.1 curve table for protection of motor

10, Temperature protection: when actual temperature measured is higher than temperature set; response time≤2s;

11, Contact capacity of output relay: 250V,5A; Contact endurance : 500000 times

12, Current error is less than 1.0%.;

13, RS485 communication function


1, Block mode control

2, Communicate with-external devices as slave through MODBUS RTU, baud rate 9600BPS,1start bit,8 data bits,1 stop bit and even parity

14, Remote control compressor: When set as remote control mode, user can remotely control the compressor.

3, Model and Specification

1, Model Description



2, Power consumption Table for Corresponding Motor

Parameter Specification	Current range (A)	Corresponding main motor power (KW)	Remark	Description
MAM860 (20)	8~20	Below 11		Fan has three levels of current, such as 0.2-2.5A, 1-5A and 4-10A, determined by current of motor
MAM860 (40)	16~40	11-18.5		
MAM860 (100)	100	22-45		
MAM860 (200)	200	55-90		
MAM860 (400)	400	110		
MAM860 (600/5)	600/5	200-250	With CT	


Table 3.2.1 Power consumption specification sheet for corresponding motor

4, Installation

1, Mechanical Installation

① Current transformer installation

The CT shall be installed at a place where the current of motor cable can be measured, thus controller can be set according to instructions on motor nameplate, the detailed dimensions is shown as below:






Figure 4.1.1. Structure dimensions of CT1 ($\phi 36$ through hole)

Figure 4.1.2. Installation dimensions of CT1




Figure 4.1.3. Structure dimensions of CT2 ($\phi 10$ through hole)

Figure 4.1.4. Installation dimensions of CT2

② Controller installation

A certain room should be left around controller for wiring. The specific dimension is shown as below:




Figure 4.1.5 Controller structure dimension




Figure 4.1.6 Hole size

2, Electrical Wiring Installation




Figure 4.2.1 Terminal arrangement diagram

Cable connection of controller:

1	Common terminal for digital input	2	Input terminal for emergency stop signal	3	Input terminal for remote control signal (on/off)
4	Input terminal used to detect oil filter	5	N/A	6	RS485+

7	RS485-	8	Terminal for ground connection	9	Terminal for the AC20V power source
10	Terminal for the AC20V power source	11	<u>N/A</u>	12	<u>N/A</u>
13	Common terminal for digital output	14	Terminal to control fan	15	Terminal to control load valve
16	Terminal to control delta contactor	17	Terminal to control star contactor	18	Terminal to control main contactor
19	Input terminal to detect the phase sequence and voltage	20	Input terminal to detect the phase sequence and voltage	21	Input terminal to detect the phase sequence and voltage
22	Power terminal for pressure sensor	23	Input terminal to receive pressure sensor signal	24	Terminal for motor CT1 input
25	Terminal for motor CT1 input	26	Terminal for motor CT1 input	27	Terminal for fan CT2 input
28	Terminal for fan CT2 input	29	Terminals for fan CT2 input	30	Terminal for discharge air temperature sensor
31	Terminal for discharge air temperature sensor				


Note :Electromagnetism coil shall be connected nearest with RC snubber during wiring

5, Control Process

1, Single Machine

1, working principle (On/off mode: Local; Load mode: Auto)

① . Press “” to start: (Y-Δstart)

The air compressor can not be started by pressing “” until 5 seconds self-checking finished. The start process of compressor is as followed: terminal 15 closed, Unloading solenoid valve is energized; 18 terminal closed, KM2 is energized;17 terminal closed ,KM3 is energized → Y start → STAR DELAY time starts record; when Y-Δtransfer time over,17 terminal open ,KM3 is de-energized and 16 terminal closed,KM1 is energized → motor operates in Δ . (KM1 and KM3 are interlocked)

②. Automatic operation control:

A, When motor enter delta status, LOAD DELAY starts, controller will load automatically after LOAD DELAY.

B, If air pressure is detected lower than UNLOADING P set,15 terminal off, Unloading solenoid valve is de-energized, and air compressor starts loading; If air pressure is detected higher than UNLOADING P set,15 terminal opens, Unloading solenoid valve is energized, and air compressor starts unloading, And accumulating unload running time, compressor unload running, air supply pressure getting down, terminal 15 closed and 16terminal energized compressor loading if pressure detected lower than P-set; If total unload time was beyond pre-Set, 16 terminal closed, 18terminal closed, Y-Δtransfer and main contactor energized, compressor will be EMPTY LONG STOP, and also press Start to restart again.

starts EMPTY LONG STOP time record ,if unloading time exceed EMPTY LONG STOP set, compressor will enter STANDBY mode; if compressor loading again within “EMPTY TIME” set(when pressure is below LOADING P or receiving load command),compressor will reset “EMPTY LONG STOP”.

C, In STANDBY mode, controller start automatically if pressure detected is below LOADING P


② . Manual loading/unloading operation under automatic status

The equipment is in unloading status under automatic status. It carries out loading by pressing loading/unloading button. If the pressure is higher than set unloading pressure, after inching of loading solenoid valve and return to unloading status. If pressure is lower than set unloading pressure value, loading solenoid valve is off electricity until supplying air pressure is higher than unloading pressure value, then it returns to unloading status. When equipment is in loading working status, if air supplying pressure is larger than set loading pressure value, it carries out unloading by pressing loading/unloading button. If pressure is higher than unloading pressure, the loading solenoid valve is on electricity until the air supplying pressure is lower than loading pressure value, the loading solenoid valve is on electricity, air compressor switches to loading operation status. When it is in automatic operation status, if pressure is lower than loading pressure, it should press unloading button and can not let air compressor works in empty loading status.

③ Continuous mode:

Continuously pressing “→” for 3sec to switch both of Continuous or Automatic mode, and it will be displayed on right top of screen; During of C mode, Unload solenoid valve is in de-energized as loading statue after start or stop, pressure controlling from Servo valve of compressor, so whatever C mode or A mode, the logistic running function is always same!

④. Normal stop:

Press “”, the loading magnetic valve will be energized, after a while of delay (stop delay), all output relay stop working.

⑤. The frequent starting control

Air compressor can not start again immediately after NORMAL STOP ,EMPTY LONG STOP or FAILURE STOP. It can start again after START DELAY.

2, Remote Automatic Control (Control Mode: Remote; Load Mode: Auto)

The remote automatic control is the same as local automatic control. The difference lies in that the Equipment’s start and stop can make inching to close and break by remote switch to realize function.

1, Local Control (Control Mode: local, Load Mode: Manual)

The start and stop control is the same as automatic control, the only difference is that after equipment starting, it is in unloading operation status. When press loading/unloading button, air compressor is loading. When air supplying pressure is larger than unloading pressure, equipment unloading automatically. If it does not press loading/unloading button to carry out loading, the equipment will keep unloading operation until empty loading operation is too longer to stop working. When it is in unloading process, press loading/unloading button to carry out loading. When it is in loading process, press loading/unloading button to carry out unloading.

2, Net Work

- ①. Controller works as slave when communication mode is set as “computer”, and communicates with monitoring center through MODBUS.
- ②. Controller and other controller can block work when communication mode is set “block” but the master only can service as 1# compressor.

3, Auto Drain Operation

Terminal 14 has timing drain faction, please find “User para” to set up the Drain time;

6, Alarm Function

1, Air Filter Alarm

The monitor displays AIR LIFE END when the running time of the air filter exhausts.

2, Oil Filter Alarm

①. Oil filter block check.

The monitor displays OIL BLOCK by checking pressure differential switch operating state.

②. Oil filter alarm

The text displays OIL LIFE END when running time of the oil filter exhausts.

3, O/A separator Alarm

The text displays “O/A LIFE END” when running time of the O/A separator exhausts.

4, Lubricating Oil Alarm

The text displays LUBE LIFE END when running time of the lubricating exhausts.

5, Grease Alarm

The text displays GREASE LIFE END when running time of the grease exhausts.

6, Belt Alarm

The text displays BELT LIFE END when running time of the belt exhausts.

7, High Discharge Air Temperature Alarm

The text display HIGH TEMPERATURE when controller detects the discharge air temperature higher than ALARM T set data in MANUFACTORY PARA.

7, Controller Protection

1, Motor Protection

MAM-860 air compressor controller provides overload, open phase, current unbalance, high voltage, low voltage protection for motor and overload protection for fan

Electronic failure	Failure Display	Reason
Overload	Display “MOTOR/FAN OVER LOAD”	Overload, bearing wear and other mechanical failure
Open phase	Display “MOTOR OPEN PHASE”	Power supply, contactor and open phase of motor
Unbalance	Display “MOTOR UNBLANCE”	Poor contact of contactor, inside open-loop of motor
High voltage	Display “HIGH VOLTAGE”	High supply voltage

Low voltage	Display “LOW VOLTAGE”	Low supply voltage
-------------	-----------------------	--------------------

2, Protection of High Discharge Air Temperature

When discharge air temperature is above the high limit of set temperature, the controller will send out the alarm to shut down the machine and This fault displays HIGHT T.

3, Protection of Air Compressor Non-reversing

When compressor stops and three phases sequence is not in order, THIS FAULT displays PHASE REVERSAL, and the controller cannot start the motor. Change the position of any arbitrary two-phase power lines and check the rotation of motor.

4, Protection of High Pressure

When the discharge air pressure is above the MAX LIM P, the controller will send out the alarm to shut down the machine and THIS FAULT displays HIGH P.

5, Protection of Sensor Failure

When pressure sensor or temperature sensor is disconnected, the controller will send out the alarm to shut down the machine and THIS FAULT displays **SENSOR FAULT.

6, Low Temperature Protection

When discharge air temperature is below LOW T PRO in manufacturing parameter, THIS FAULT displays P SENSOR FAULT two minutes after compressor turns on, the controller will send out the alarm to shut down the machine.

8, Troubleshooting

1, This Fault Review

Failure stop caused by the external parts of controllers may be removed by checking THIS FAULT or HISTORY FAULT , method is shown as below:

Press “” to move the cursor to “RUN PARAMETER” menu, then press “” , the secondary menu would be prompted out:

MOTORS /FAN CURRENT TOTAL RUN TIME THIS RUN TIME CLR LIFE TIME
--

HISTORY FAULT PROD DATE NO. THIS FAULT COM STATUS.
--

Move cursor to THIS FAULT press “” to switch to the following menu:

STOP:T SENSOR FAULT
 0170℃

User can reset the error according to the following information

2, Common Failures and Causes


Failure	Reason	Solution
High temperature of discharge air	Bad vent condition, Oil shortage etc.	Check the vent condition and lubricant amount etc.
Temperature Sensor Failure	Cable off or PT100 failure	Check the wiring and PT100
High Pressure	Pressure too high or the pressure sensor failure	Check the pressure and the pressure converter
Pressure Sensor Failure	Cable off, Sensor failure or the cable connect reversed	Check the wiring and pressure converter
Open Phase	Power open phase or the contactor terminal failure	Check the power and contactors
Overload	Voltage too low, tubes block, bearing wear off or other mechanical failure or wrong set data etc.	Check the set data, voltage, bearings, tubes and other mechanical system.
Unbalance	Power unbalance, contactor failure or the internal open loop of the motor	Check the power, contactor and the motor
Wrong Phase Sequence	Reversed phase sequence or open phase	Check the wiring
Overload during start	Master start time set to less than the star delta delay time	Reset the master start time to be longer than star delta delay + 2 seconds
Main Contactor shakes frequently	The emergency button loose, controller reset by interference	Check the wiring; if the coil of contactor connect with surge absorber or not

9, Block mode control and net work

1, Block mode control

① Block control explanation

MAM860 controller can block operate with MAM series compressor (with communication function).16 pcs compressors are allowed in the net at most. The cable connection for block mode control is as below...



一号机



二号机


Picture 9.1.1


Compressor with net communication address 0001 is master, others are slave. Any one MAM series compressor can be set as master or slave.


② Block mode setting


1. Set as master:



In main menu, press “” to enter select menu and choose USER PARAMETER, press “” and switch to the menu below:



Move the cursor to OPERATION MODE, press “” to switch to the menu below.



Set COM MODE as BLOCK, COM ADD as “0001”, return to the previous menu, move the cursor to BLOCKING MODE press “” to switch to the menu below



According to user requirement, set BLK STATE as MASTER, set ALTER TIME, BLK NUMER, BLK MIN, BLK MAX, BLK DELAY according to user's need. After setting, controller needs to be powered off and restarts to the setting.


2, Set as slave:

When MAM controller serves as slave, it is only necessary to set COM MODE as BLOCK mode, set COM ADD from 2-16 with sequence according to the quantity of compressors, BLK STATE set as SLAVE.



1, Start, stop block control:


Make sure block cables connect correctly and the parameter of compressors in net set correctly. Activate master,

master controls the compressors in net automatically according to the air pressure detected . Block control stops at the same time when manually stop the master so master will no longer send command to compressor in net .



2, Block communication receiving and sending message:

The message received and sent by RS485 can be displayed by the corresponding indication screen which is convenient for customer to make sure if they have received and feedback data in BLOCK mode or COM MODE. The method to switch to communication menu is as below: press “” in main menu and enter main menu and select run parameter and move down the cursor to communication menu, press “” and switch to the COM MODE menu as below



When controller receives data, RX “—” and “*” display alternately, When sends data, TX: “—” and “*” display alternately. When controller is in block control or communicates with monitoring center ,user can confirm the establishment of communication through this menu.

2.Net Work

MAM860 controller supports MODBUS RTU protocol and can serve as slave when connect with other equipment and supports 03、 06、 16 MODBUS command. Communication baud rate: 9600BPS, 1 start bit, 8 data bits, 1 stop bits and even parity. For MODBUS register address, please see MODBUS communication manual.

10. Wiring diagram

